



S Negative Trigger - Connect to the Siren Output module on your Alarm Panel

+ 12VDC Power (Positive on Alarm Panel)

T Tamper Output - Wired to a zone on your alarm panel, but not required for basic operation