


Do Not Disturb

Configuration via Web

1. Log in web page > Phone settings > Features > DND setting, and select the "DND option" is Phone or Line.
2. Check "Enable DND Timer" > Apply.

Voice mail

1. To access your voice mail box, press  key, number of messages will be indicated if provided by your server or pbx.

Network connect

Using Ethernet


1. The power on the device and connect the WAN port of the phone to the RJ45 socket of a hub/switch or a router (LAN side of the router) using the Ethernet cable.
2. The default is DHCP mode.

Using Wi-Fi

1. Enter "#*107" in standby mode > Basic > WLAN
2. Configuration via Web. Log in web page > Network > Wi-Fi settings, check "Wi-Fi Enable" and add Wi-Fi information

Fanvil

V1.4



H5W

Quick Installation Guide

Fanvil Technology Co., Ltd

Website: www.fanvil.com

E-Mail: sales@fanvil.com support@fanvil.com


Tel: +86-755-2640-2199 Fax: +86-755-2640-2618

Add: 10/F Block A, Dualshine Global Science Innovation Center,
Honglang North 2nd Road, Bao'an District, Shenzhen, China


Fanvil Technology Co., Ltd
www.fanvil.com

P/N:CJBA100177D0

Packaging list



IP Phone



Handset




Handset Cord



Ethernet Cable




Quick Installation Guide



Power Adapter
(Optional)

Screen icon



Keys features



Soft keys



Message waiting indicator



Hold key, Hold/Resume the call



Call transfer key



Voice message key



Redial key, Access to redial the last record



In idle mode: Activate/deactivate silent mode
In communication mode: mute/un-mute a call



In idle mode or during ringing: increase or decrease ringer volume
In communication: increase or decrease handset or hands-free volume



Hands-free key, Activate/deactivate hands-free


Installation the device

Please follow the instructions in below picture to install the device.

Connecting to the Device

Please connect power adapter, network, PC and handset to the corresponding ports as described in below picture.

- ① USB port: connect USB device .(Recharge)
- ② PC port: connect PC.
- ③ Network port: connect LAN or Internet.
- ④ Handset port: connect IP Phone handset.
- ⑤ Power port: connect the power adapter.



Configuration

Configuration via Phone

1. Get the IP address: Press the "#" key for more than 3 seconds to display the IP address on the screen.
2. Login: Input the IP address in the web browser. The PC and phone should be in the same IP address segment (The default username and password are both "admin" .)
3. Configure: Select network/Account, etc. And fill the relevant content.
4. Save the configuration.

Making a call

1. **Pre-dialing:** enter the phone number and pick up the handset.
2. **Direct dialing:** lift the handset and enter the phone number.
3. **Handsfree:** enter phone number and press or vice versa.
4. **Memory key:** press memory key.

Accepting a call

1. **Using the handset:** pick up the handset.
2. **Using the hands-free:** press .

Redial

1. Press key, redial a call number.

Call Mute

1. Press to Mute the microphone during the call.
2. Press again to un-mute the conversation.

Putting a call on hold

1. Press key during an active call.
2. To resume the call, press key.

Call transfer

Attended transfer:

1. Press key during the active conversation, the call is put on hold.
2. Dial the second telephone number and press "Dial" or "#".
3. When the call is answered, then press key to complete the operation.

Blind transfer:

1. Press key during the active conversation, the call will be on hold.
2. Then enter the 2nd telephone number and press key.

Call logs

Query via Web

1. Log in web page > call logs, display a list of all calls.
2. User can filter the call logs by the call log types, in, out, missed, or all.

Programmable keys

Configuration via Web

1. Log in web page > Function key, Select the function and fill in the number in the value items.